


[illegible]

Notes
Do not scale.
Use figured dimensions only.
This drawing is to be read in conjunction with all relevant specifications and drawings.
All dimensions to be checked on site.
In the event of any discrepancies between drawings, the contractor is to inform the Architect immediately.

PLANNING

ELEVATIONS C: EXISTING/PROPOSED

	Stage:	Int. Job No:
1:200 @A0	P	23005